




Air Conditioning and Climate Control Course L752



L752 Presentation (Version 2.95)

LEXUS Technical Training

© 2008 Toyota Motor Sales, U.S.A., Inc.

All rights reserved. This book may not be reproduced or copied in whole or in part by any means without the written permission of the University of Toyota, Toyota Motor Sales, U.S.A., Inc.

Course L752: Air Conditioning and Climate Control

Introduction	Course Topics	2
	Section Overview	3
	Typical A/C Problems	4
	Most Common Sources of Problems	5
	Course Overview	6
	General Safety	7
	Refrigerant Safety	7
Heating and Cooling	Section Overview	8
	Heating System Components	9
	PTC Heater	10
	Electric Water Pump	11
	Cooling System Principles	12
	Process of Refrigeration	12
	Vaporization	13
	Condensation	13
	Compression	14
	Expansion	14
	Cooling System Processes	15
	Cooling System Components	15
	Refrigerant Recovery & Charging Station	16
	Refrigerant Oil	16
	Sight Glass Inspection	17
	Recovery and Charging Station Demo and Normal System Operation Worksheet.....	18
	Compressor Types	19
	Compressor	19
	Compressor Clutch	19
	Swash Plate Compressors	19
	Electric Compressors	19
	Condenser & Receiver-Drier	20
	Condenser	20
	Receiver-Drier	20
	Expansion Valve	21
	Evaporator	22
	Symptoms of Improper Charge Worksheet	23
	Symptoms of Improper Charge	24
	Significant Undercharge	24
	Slight Undercharge	25
	Overcharge	26
	A/C Pressure Gauge Diagnosis Worksheet	27
	Compressor Clutch Replacement	28
Air Distribution	Section Overview	29
	Air Flow and Outlet Modes	30
	Air Outlet Modes	31
	Air Inlet Damper	32
	Blower Motor	32
	Air Mix Temp. Control	32
	Max Cool Damper	32
	Outlet Mode Dampers	32
	Film Dampers	33
	Rotary Airmix Control Door	34
	Air Distribution Testing Worksheet	35

Course L752: Air Conditioning and Climate Control

Electronic Controls	Section Overview	36
	Thermistors	37
	Evaporator Temperature Sensor	37
	Room Temperature Sensor	38
	Ambient Temperature Sensor	39
	Vehicle Speed Sensor	39
	Solar Sensor	40
	Duct Sensor	41
	Infrared Sensor	42
	Smog Ventilation Sensor	43
	Air Quality Control	44
	Pressure Sensor	45
	Compressor Lock Sensor	46
	Servomotors	47
	Air Inlet Mode Control	47
	Air Mix Control	47
	Outlet Mode Control	47
	Cool Air Bypass Servomotor	47
	Blower Motor	48
	Sensors and Actuators Worksheet	49
Diagnosis	Section Overview	50
	Systematic Diagnosis	51
	6-Step Diagnostic Process	51
	Customizable Settings	52
	Check Mode Procedure	53
	Actuator Check (Step Test)	54
	Diagnostic Trouble Codes	55
	Customizable Settings Worksheet	56
	Check Mode and DTCs Worksheet	56
	Diagnostic Exercises Worksheet	57
	Repairs	58
	Component Replacement	58
Additional Heating and Cooling Systems	Section Overview	59
	Rear Air Conditioning Unit	60
	Cool Box	61
	Peltier Element	62
	Model Differences	63
	Differences in Climate Control Seat Systems	63
	Blinking Light Diagnosis	64
Application Chart	Application Chart	65
Glossary	Glossary	66